

EW-7611ULB



Edimax Technology Co., Ltd.

No. 278, Xinhu 1st Rd., Neihu Dist., Taipei City, Taiwan Email: support@edimax.com.tw

Edimax Technology Europe B.V.

Fijenhof 2, 5652 AE Eindhoven, The Netherlands Email: support@edimax.nl

Edimax Computer Company

3444 De La Cruz Blvd., Santa Clara, CA 95054, USA Live Tech Support: 1(800) 652-6776 Email: support@edimax.com

I.	Produ	ct Information	1
	I-1.	Package Contents	1
	I-2.	LED Status	
	I-3.	System Requirements	1
	I-4.	Safety	2
II.	Install	ation	3
III.	Windo	DWS	4
	III-1.	Driver Installation	4
	III-2.	Driver Uninstallation	8
IV.	Mac C	DS	9
	IV-1.	Driver Installation	9
	IV-2.	Driver Uninstallation	14
v.	Disabl	ling Network Adapters	15
	V-1.	Windows 7	15
	V-2.	Windows 8.1 & 10	16
	V-3.	Mac	17
VI.	Using	The Adapter	18
	VI-1.	Windows	18
	VI-2.	Mac	22

Multi-Language Quick Installation Guide (QIG) on the CD

Čeština: Českého průvodce rychlou instalací naleznete na přiloženém CD s ovladači

Deutsch: Finden Sie bitte das deutsche S.A.L. beiliegend in der Treiber CD

Español: Incluido en el CD el G.R.I. en Español.

Français: Veuillez trouver l'français G.I.R ci-joint dans le CD

Italiano: Incluso nel CD il Q.I.G. in Italiano.

Magyar: A magyar telepítési útmutató megtalálható a mellékelt CD-n

Nederlands: De nederlandse Q.I.G. treft u aan op de bijgesloten CD

Polski: Skrócona instrukcja instalacji w języku polskim znajduje się na załączonej płycie CD

Português: Incluído no CD o G.I.R. em Portugues

Русский: Найдите Q.I.G. на русском языке на приложеном CD

Türkçe: Ürün ile beraber gelen CD içinde Türkçe Hızlı Kurulum Kılavuzu'nu bulabilirsiniz

Українська: Для швидкого налаштування Вашого пристрою, будь ласка, ознайомтесь з інструкцією на CD

I. Product Information

I-1. Package Contents







I-2. LED Status

LED	LED Status	Description
WLAN	On	Wireless activity: transmitting or receiving data.
	Off	No wireless activity.



I-3. System Requirements

- Windows 7 10, Mac OS X 10.7 10.11
- USB 2.0 Port
- Hard Disk: 100MB
- CD-ROM Drive

I-4. Safety

In order to ensure the safe operation of the device and its users, please read and act in accordance with the following safety instructions.

- **1.** The wireless adapter is designed for indoor use only; do not place the wireless adapter outdoors.
- **2.** Do not place the wireless adapter in or near hot/humid places, such as a kitchen or bathroom.
- **3.** The wireless adapter contains small parts which are a danger to small children under 3 years old. Please keep the wireless adapter out of reach of children.
- **4.** There are no user-serviceable parts inside the wireless adapter. If you experience problems with the wireless adapter, please contact your dealer of purchase and ask for help.
- **5.** The wireless adapter is an electrical device and as such, if it becomes wet for any reason, stop using it immediately. Contact an experienced electrical technician for further help.

1. Switch on your computer and insert the USB adapter into an available USB port of your computer.



2. Insert the included CD-ROM into the CD drive of your computer.



The setup wizard is also available for download from the Edimax website.

3. For **Windows** users the setup wizard will open. For **Mac** users the CD's "Mac" folder will open.



If the CD doesn't auto-run or if you downloaded the setup wizard, please browse to the "Autorun" or "Mac" folder of the CD for Windows or Mac users respectively.

4. Please follow the instructions in the appropriate chapter for your operating system.

III-1. Driver Installation



If the CD didn't auto-run, please open the "Autorun.exe" file to start the setup wizard.



1. Click the EW-7611ULB wireless USB adapter to continue.



2. Click "Install Wi-Fi Driver" to install the Wi-Fi drivers.



3. Click "Next" to continue and follow the instructions on-screen until installation is complete.



4. You need to install the Bluetooth drivers next, so select restart your computer later and click "Finish".



5. Click "Install Bluetooth Driver" to install the Bluetooth drivers.



6. Click "Next" to continue and follow the instructions on-screen until installation is complete.



7. You need to restart your computer before using the adapter. Choose whether to restart now or later and click "Finish" to continue.



8. Click "Exit" to close the setup wizard.

	6			<i>~~</i> 44	
	Install Wi-Fi Driver	Install Bluetooth Drive	Multi-language Pr QIG	lecteder Adobe Reader	
Back					Exit
ΣΟΪΜΑΧ	Wireless N	1150	ww	w.edimax.com	🗟 Contact Us



The multi-language QIG is also included on the CD-ROM. To open it click "Multi-language QIG".

9. Please disable any other wireless adapters as described in V. Disabling Network Adapters. Then, Windows users can connect to an available Wi-Fi network or Bluetooth device as usual. For guidance on doing so, please refer to VI. Using The Adapter.

III-2. Driver Uninstallation

To uninstall drivers for your adapter, use the **Windows Control Panel** built-in **Programs and Features**, **Uninstall a Program** or **Add or Remove Programs** feature. An example is shown below:



3. Select Edimax Wi-Fi N150 (or similar) and Edimax Bluetooh 4.0 (or similar) and click Uninstall.

Uninstall or change a program

To uninstall a program, select it from the list and then click Uninstall, Change or Repair.

Organise - Uninstall						
Name 7	Publisher	Installed On	Size	Version		
😹 Edimax Wi-Fi N150 Bluetooth4.0 Wi-Fi USB Adapter D	Edimax Technology Co.	10/05/2016	11.0 MB	1.00.0272		
🖇 Edimax Bluetooth 4.0 USB Adapter Driver 💦 🔪 🍗	Edimax Technology Co., Ltd	10/05/2016	16.6 MB	3.886.880.030916		
🖟 Microsoft Visual C++ 2012 Redistributable (x64) - 11.0	Vicrosoft Corporation	10/05/2016		11.0.51106.1		
Microsoft Visual C++ 2008 Redistributable - x64 9.0.3	Mice oft Corporation	08/05/2016	1.62 MB	9.0.30729.4148		
III Microsoft Visual C++ 2008 Redistributable - x86 9.0.3	Microson. Corporation	08/05/2016	6.55 MB	9.0.30729.4148		
Opera Stable 37.0.2178.32	Opera Software	08/05/2016	258 MB	37.0.2178.32		
1 Microsoft Office 365 Small Business Premium - en-us	Microsoft Corporation	08/05/2016	968 MB	16.0.6868.2060		

IV. Mac OS

IV-1. Driver Installation



1. Open the "RTLWLANU_MacOS.." folder and double click the "Installer.pkg" file to open the driver installation wizard.



2. Click "Continue" to proceed to the next step.



3. The next screen displays important information, please read it carefully. Click "Continue" when you are ready to continue.

	Important Information					
Introduction	This is the Mac OS X driver for Wireless USB Adapter. If you have already installed an older version of software, please uninstall it first by executing "Uninstall.pkg". Then you can install this version of software					
Read Me	successfully. Otherwise, this software can not be upgraded successfully.					
License	The system is required to reboot after the driver is installed, so please close all the other applications before installing this software. After the					
Destination Select	system boots up and you enter the system, please follow the following steps to configure the network:					
Installation Type	Select the "System Preference" from the system menu. Select and launch the "Network" item in the "System Preference"					
Installation	folder.					
Summary	 From the "Configure" list, select the correct adapter and configure it. Configure the settings. Click the "Save" button. Then you can connect to the WLAN. 					

4. Select a language (the default language is English) and click "Continue" to install the driver.

	Software License Agreement				
Introduction		English	٢		
Read Me	Copyright (c) 20	L			
License					
Destination Select					
Installation Type					
Installation					
Summary					
	Print	Save	Go Back Co	ontinue	

5. To read the software license click "Read License" and then click "Agree" to confirm you agree to the terms. You must agree to the terms to continue installing the software.

0	0	🥪 Install Wir	eless USB Adapter Driver	<u></u>			
		To continue installing the so the software license agreem	ftware you must agree to the te lient.	erms of			
0	Intr	Click Agree to continue or click Disagree to cancel the installation and					
0	Rea	quit the Installer.					
	Lic						
	De	Read License	Disagree	Agree			
	Ins						
	Install	ation					
	Summ	ary					
		Print	Save Go B	ack Continue			

6. If prompted, select which user to install the software for and click "Continue".



7. Click "Install" to install the driver.

	Standard Install on "eaglemacpro"
 Introduction Read Me License Destination Select Installation Type Installation Summary 	This will take 13.1 MB of space on your computer. Click Install to perform a standard installation of this software for all users of this computer. All users of this computer will be able to use this software.

8. You may be prompted to enter your system/administrative password before the installation can begin. Enter your password and click "Install Software".

	Installer is t your passw			ftware. Type
-	1	1		
	Username:			
	Password:			

9. You will be prompted that you must restart your computer when the installation is complete. Click "Continue Installation" to proceed.

Introductic	🔨 mus	st restart your c	finishes installing, ye omputer. Are you sur the software now?	
Read Me		Cancel	Continue Installati	on software ter will be
Destination Selec	rt			
Installation Type	e			
Installation				
Summary				
			Change	Install Location

10. Please wait while the driver is installing.



11. When the installation is complete, you will see the following screen informing you that "The installation was successful". Click "Restart" to restart your computer.

	The installation was completed successfully.
Introduction Read Me License Destination Select Installation Type Installation Summary	The installation was successful. The software was installed.
	Click Restart to finish installing the software.

12. Next, please disable any other wireless adapters as described in V.Disabling Network Adapters. Then you can connect to a Wi-Fi network as described in VI. Using The Adapter.

IV-2. Driver Uninstallation

1. Open the "RTLWLANU_MacOS.." folder.

RTLWIanU_MacOS1...opDownMenu_Rev9

2. Double click the "Uninstall.pkg" file and follow the on-screen instructions.

😺 Uninstall.pkg

V. Disabling Network Adapters

To ensure that your USB wireless adapter can function correctly, it is recommended that you disable any other existing wireless network and Bluetooth adapters installed on your computer. If you are unsure how to do so, you can refer to the user manual for your computer, or follow the examples below.

V-1. Windows 7

Go to Start > Control Panel. Click View network status and tasks > Wireless Network Connection and click Disable.

-		
Control Panel +	Network and Internet Network and Sharing Center	 ✓ ✓
Control Panel Home	View your basic network information and	et up connections
Manage wireless networks Change adapter settings Change advanced sharing	WIN7-PC EDIMAX (This computer)	See full map
settings	View your active networks	Connect of Connect
	EDIMAX Work network	Access type Internet Connections: and Wireless Network Connection (EDIMAX)
	Connect to a network Connect or reconnect to a wireless, wired, d	c, or VPN connection; or set up a router or access point. ial-up, or VPN network connection. twork computers, or change sharing settings.
See also HomeGroup Internet Options Windows Firewall	Troubleshoot problems Diagnose and repair network problems, or g	et troubleshooting information.

V-2. Windows 8.1 & 10

- 1. Go to File Explorer > Network (right click) > Properties > Change adapter settings.
- 2. Right click your wireless adapter, select "Properties" and then "Disable".



- V-3. Mac
- **1.** Select "System Preferences" from the dock.





3. All of your network connections will be displayed, as shown below. Select "Wi-Fi" from the left panel.



System Preferences

4. Click "Turn Wi-Fi" off in the main panel.



VI. Using The Adapter

After you have installed the driver and if necessary disabled other adapters, Windows users can connect to a Wi-Fi network or Bluetooth device as usual. Mac users need to connect to a Wi-Fi network using the included utility, as described in **VI-2. Mac**

VI-1. Windows

Below is an example of how to connect - the process may vary according to your Windows edition.

1. Click the network icon (examples below) in the system tray and select "Connect to a network".



2. Search for the SSID of your Wi-Fi network and then click "Connect". If you set a password for your network, you will then be prompted to enter it.



3. After correctly entering your password, you will be successfully connected to your Wi-Fi network.



4. To connect to a Bluetooth device, go to Windows Bluetooth settings by using the search bar, or by right clicking the Bluetooth icon in the task bar and choosing **Add a Bluetooth Device**.

		Add a Bluetooth Devi	e de la companya de l		
		Allow a Device to Con			
		Show Bluetooth Dev	ice		
		Join a Personal Area N	etwork		
		Open Settings			
		Remove Icon			
(ی ا	• 🍬 ïl 🖓 🚍 E	5/13/2016		
← Set	ttings		- D ×		
र्ह्रेडे De	EVICES		Find a setting		
Printers &	scanners		Manage Bluetooth devices		
Connected devices			Your PC is searching for and can be discovered by Bluetooth		
Bluetooth			devices.		
Mouse & touchpad			TS der iPhone Ready to pair		
Typing					
AutoPlay			Related settings		
USB			More Bluetooth options		
			Send or receive files via Bluetooth		

5. Select your Bluetooth device and click Pair and then confirm the passcode.



6. Your Bluetooth device will display **Connected** and is now available for use.





VI-2. Mac

1. Click the new USB adapter icon from the menu in the top right of your Mac desktop and select your Wi-Fi network as you usually would.



2. Enter the password (network key) for the Wi-Fi network and click "Join".

AES passwork	k "wifi hotspot" requires a WPA2-PS rd
Password	:
	Show password

3. After entering your password, you will be successfully connected to your Wi-Fi network and the icon will display the Wi-Fi signal strength.

ad	63% 🛇 🔿 87% 🔳	注	Sun 20:52
	USB-WiFi: On		
	Turn USB-WiFi Off		
~	wifi hotspot		≜
	iTaiwan		((:-
	NewTaipei		([[+
	Join Other Network		
	WPS		жw
3	Open Wireless Utility		жo

4. You can use the other items in the menu to switch your USB adapter on/off, join another network (manually enter SSID name) display WPS PIN or activate WPS push button mode.

WPS (Wi-Fi Protected Setup) is a simple, alternative way to establish connections between WPS compatible devices. Most modern wireless network devices feature a built-in WPS button, which activates WPS on that device. When WPS is activated in the correct manner and at the correct time for two compatible devices, they will automatically connect to each other.

WPS can be activated via the Wi-Fi utility, which has the same effect as physically pushing the WPS button (known as PBC or "push button configuration").

PIN code WPS is an additional variation of WPS which can be activated from a device's web user interface, and includes the use of a PIN code between the two devices for identification and verification.



COPYRIGHT

Copyright © Edimax Technology Co., Ltd. all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission from Edimax Technology Co., Ltd.

Edimax Technology Co., Ltd. makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability, or fitness for any particular purpose. Any software described in this manual is sold or licensed as is. Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Edimax Technology Co., Ltd. reserves the right to revise this publication and to make changes from time to time in the contents hereof without the obligation to notify any person of such revision or changes.

The product you have purchased and the setup screen may appear slightly different from those shown in this QIG. The software and specifications are subject to change without notice. Please visit our website www.edimax.com for updates. All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient or relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio technician for help.

FCC Caution

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.

Federal Communications Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 0.5 cm during normal operation.

RED Compliance Statement

Compliance with 2014/53/EU Radio Equipment Directive (RED)

In accordance with Article 10.8(a) and 10.8(b) of the RED, the following table provides information on

the frequency bands used and the maximum RF transmit power of the product for sale in the EU:

Frequency range (MHz)	Max. transmit power (dBm)
2412-2472	18.34 dBm
2402-2480 (BT)	5.64 dBm
2402-2480 (BLE)	7.42 dBm

A simplified DoC shall be provided as follows: Article 10(9)

Hereby, Edimax Technology Co., Ltd. declares that the radio equipment type N150 WiFi Bluetooth 4.0

USB Adapter is in compliance with Directive 2014/53/EU

The full text of the EU declaration of conformity is available at the following internet

address: http://www.edimax.com/edimax/global/

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

EU Countries Intended for Use

The ETSI version of this device is intended for home and office use in Austria, Belgium, Bulgaria, Cyprus, Czech, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Turkey, and United Kingdom. The ETSI version of this device is also authorized for use in EFTA member states: Iceland, Liechtenstein, Norway, and Switzerland.

EU Countries Not Intended for Use None

EU Declaration of Conformity

English: This equipment is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU, 2014/35/EU. Français: Cet équipement est conforme aux exigences essentielles et autres dispositions de la directive 2014/53/EU, 2014/35/EU. Čeština: Toto zařízení je v souladu se základními požadavky a ostatními příslušnými ustanoveními směrnic 2014/53/EU, 2014/35/EU. Polski: Urządzenie jest zgodne z ogólnymi wymaganiami oraz szczególnymi warunkami określonymi Dyrektywą UE 2014/53/EU, 2014/35/EU. Română: Acest echipament este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 2014/53/UE, 2014/35/UE. Это оборудование соответствует основным требованиям и положениям Директивы Русский: 2014/53/EU, 2014/35/EU. Ez a berendezés megfelel az alapvető követelményeknek és más vonatkozó irányelveknek Magyar: (2014/53/EU, 2014/35/EU). Türkçe: Bu cihaz 2014/53/EU, 2014/35/EU direktifleri zorunlu istekler ve diğer hükümlerle ile uyumludur. Українська: Обладнання відповідає вимогам і умовам директиви 2014/53/EU, 2014/35/EU. Slovenčina: Toto zariadenie spĺňa základné požiadavky a ďalšie príslušné ustanovenia smerníc 2014/53/EU, 2014/35/EU. Dieses Gerät erfüllt die Voraussetzungen gemäß den Richtlinien 2014/53/EU, 2014/35/EU. Deutsch: El presente equipo cumple los requisitos esenciales de la Directiva 2014/53/EU, **Español:** 2014/35/EU. Italiano: Questo apparecchio è conforme ai requisiti essenziali e alle altre disposizioni applicabili della Direttiva 2014/53/EU, 2014/35/UE. Nederlands: Dit apparaat voldoet aan de essentiële eisen en andere van toepassing zijnde bepalingen van richtlijn 2014/53/EU, 2014/35/EU. **Português:** Este equipamento cumpre os requesitos essênciais da Directiva 2014/53/EU, 2014/35/EU. Norsk: Dette utstyret er i samsvar med de viktigste kravene og andre relevante regler i Direktiv 2014/53/EU, 2014/35/EU. Denna utrustning är i överensstämmelse med de väsentliga kraven och övriga relevanta Svenska: bestämmelser i direktiv 2014/53/EU, 2014/35/EU. Dette udstyr er i overensstemmelse med de væsentligste krav og andre relevante Dansk: forordninger i direktiv 2014/53/EU, 2014/35/EU. suomen kieli: Tämä laite täyttää direktiivien 2014/53/EU, 2014/35/EU. oleelliset vaatimukset ja muut asiaankuuluvat määräykset.

FOR USE IN AT BE CY CZ OK EE (†) (FR DE GR (†) (E) (T) (V) (T) (U) (MT) (N) (P) (PT) (SK (S) (E) (SE) (GB (S) (U) (N) (C+) (BG (R) (R) (TR) (UA)



WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Declaration of Conformity

We, Edimax Technology Co., Ltd., declare under our sole responsibility, that the equipment described below complies with the requirements of the European Radio Equipment directives.

Equipment: N150 WiFi Bluetooth 4.0 USB Adapter

Model No.: EW-7611ULB

The following European standards for essential requirements have been followed:

Directives 2014/53/EU

Spectrum	:	EN 300 328 V2.1.1 (2016-11)
EMC	:	EN 301 489-1 V2.1.1 (2017-02)
		EN 301 489-17 V3.1.1 (2017-02)
EMF	:	EN 62311:2008
Safety (LVD)	:	IEC 60950-1:2005 (2 nd Edition)+Am 1:2009+Am 2:2013
		EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013

Edimax Technolo Fijenhof 2, 5652 AE Eindhov The Netherlands		a company of : Edimax Technology Co., Ltd. No. 278, Xinhu 1st Rd., Neihu Dist., Taipei City, Taiwan
Signature:		Taiwaii
Printed Name:	David Huang	
Title:	Director	
	Edimax Techno	ology Europe B.V.

	Date of Signature: Signature:	June, 2017
CE	Printed Name: Title:	Albert Chang Director Edimax Technology Co., Ltd.